

CAUTION

- 1. All the safety and operating instructions should be read before the appliance is operated.
- 2. All operating and user instructions should be followed.
- 3. The appliance should not be used near water for example, near a bathtub,washbowl,kitchen sink,Laundry tub, in a wet basement,or near a swimming pool, ect. It should not be exposed to dripping or splashing water, and no Objects filled with liquid, such as a vase, should be placed on the appliance.
- 4. Warning: To reduce the risk of fire of electric shock, do not expose this appliance to rain or moisture.
- 5. The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; Or placed in a built - in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings.

PACKAGE CONTENTS

Speakers	1pc
Ореакега	ipc
3.5mm to 3.5 stereo cable	1pc
USB cable	1pe
Operation manual	1pc
	USB cable

1	3	
	2005	

END-USER'S COPY WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name:
Last Name:
Address:
Contact No.:
Product Name:
Model No.:
Serial No.:
Date Purchased:
Invoice No.:
Retail Outlet Where Purchased:
Retail Outlet Where Purchased.

SECTION 1

2

SF80 WARRANTY CARD

DISTRIBUTOR'S COPY WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name:
Last Name:
Address:
Contact No.:
Product Name:
Model No.:
Serial No.:
Date Purchased:
Invoice No.:
Retail Outlet Where Purchased:

SECTION 2

3

(Please print the name & address)

正反面对应

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of \mathcal{K} F820 product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

In the warranty covers services by our Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

2. Repair services will be provided for defects arising from normal to the following particular to the

usage for the following period, commencing from the date of purchase from our **F89** Authorised Dealer. (Parts would be replaced when necessary)

- A. Failure to present the warranty card and receipt when
- servicing is required.
 Full particulars not clearly shown or alterations made against

Full particulars not clearly shown or alterations made again the actual information.

For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.

B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse,

unaturionised technicians of which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occuring in transit by or from the customer.

C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd. Add: Fenda Hi-Tech Park,Zhoushi Road,Shiyan,Baoan,Shenzhen,China P.C.: 518108 Http://www.fenda.com

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of FRO product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service area follow: service are as follow:

The warranty covers services by our **B80** Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

 Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our 🗷 🕬 Authorised Dealer. (Parts would be replaced when necessary)

servicing is required.
Full particulars not clearly shown or alterations made against

the actual information.

For e.g.: Alteration of the date of purchase, serial

numbers-altered or removed.


B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse,

negligence or accident. This guarantee does not cover damage occuring in transit by or from the customer.

C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage


Shenzhen Fenda Technology Co., Ltd. Add: Fenda Hi-Tech Park,Zhoushi Road,Shiyan,Baoan,Shenzhen,China P.C.: 518108 Http://www.fenda.com

BUTTON CONTROLS



- 1. $\mbox{\ensuremath{\$}}$ Short press to Bluetooth source, long press entering pairing mode,
- 2. Short press to switch Bluetooth, USB and AUX sources.
- LED colors: blue for Bluetooth, green for USB, red color for AUX. the current pattern is Bluetooth and LED will be blue. 3. 🕟 / 🛏 Short press to decrease volume and and long press to select
- previous song, under Bluetooth and USB mode.
- 4. 40 / M Short press to increase volume and and long press to select next song, under Bluetooth and USB mode.
- 5. M Short press to pause/play music.

CONNECTION DIAGRAM



CHARGING

- 1,Connect mini USB port of unit to computer or charger is USB port using USB cable included in the package.
- 2. Charging LED bright in cycle during and all bright after finishing charging.
- 3. Recommend to charge the unit once every month and turn off the

USB mode, Support nondestructive music format flac/ ape/ wav/ mp3 and wma, the biggest support 32GB USB driver.

OPERATION MANUAL

Turn "on/off" switch at side. After power on, E200 PLUS will automatically search the Bluetooth device. If the device paired before, E200 PLUS will connect automatically. If can't find paired device, E200 PLUS will enter pairing mode automatically, blue LED under pairing button flashes quickly. 1. Active "Bluetooth" function on your device and search for "Fenda Minibar". Enter "0000" if your device asks for the PIN code...

2. After pairing successfully, blue LED bright, and ready for playing music. Recommend to adjust suitable volume before playing music

Output power: 2.5WX2(RMS)

Input: 5V== 1A Speaker unit: 2" 4Ω full range driver Frequency Response: 55Hz-20KHz S/N Ratio: ≥70dB Separation: ≥50dB

Dimension: L417XW73XD53mm

✓ F8D奋达科技 时 20171221 订单号 尺寸/套装数 YFE17476 75X154mm (成型) 300X154mm(展开) 品 公司型号 客户型号 牌 E200 PLUS 材质/厚度 E200 PLUS 128g铜版纸 盒型/页码/条码 版 料 号 本 设计内容 说明书 17.7.030.1526 折页 <u>电子</u> 软件 <u>结构</u> 电声 刘秀军 <u> 1</u>1/ 务 陈岸君 字体要求 如文件 设计者 标准化 李洪波 李功润 印刷/表面处理 单黑正反印刷 工艺/单双泊/AB同版 此物料刀模同料号: 17.7.030.0847 备 注 公差/用量 正负公差 (1mm)